


SKUTT

KM Amperage by Section

Model	Voltage	Phase	Amp1	Amp2	Amp3
KMT/KM-1627PK	240	1 & 3	38	21	38
KMT/KM-1627PK	208	1 & 3	44	25	44
KMT/KM-1627PKLF	240	1 & 3	27	14	27
KMT/KM-1627PKLF	208	1 & 3	27	15	27
KMT/KM-1231PK	240	1 & 3	25	20	25
KMT/KM-1231PK	208	1 & 3	29	22	29
KMT/KM-1227PK	240	1 & 3	23	13	23
KMT/KM-1227PK	208	1 & 3	27	15	27
KMT/KM-1227	240	1 & 3	17	14	17
KMT/KM-1227	208	1	17	14	17
KMT/KM-1227	208	3	18	16	18
KMT/KM-1222	240	1 & 3	20	8	20
KMT/KM-1222	208	1	20	8	20
KMT/KM-1222	208	3	23	9	23
KMT/KM-1218	240	1 & 3	14	19	14
KMT/KM-1218	208	1 & 3	14	19	14
KMT/KM-1027	240	1 & 3	17	14	17
KMT/KM-1027	208	1	17	14	17
KMT/KM-1027	208	3	18	16	18
KMT/KM-1022	240	1 & 3	20	8	20
KMT/KM-1022	208	1 & 3	20	8	20
KMT/KM-1018	240	1	20	20	N/A
KMT/KM-1018	208	1	20	20	N/A
KMT/KM-822	240	1 & 3	14	6	14
KMT/KM-822	208	1 & 3	16	7	16
KMT/KM-818	240	1	13	13	N/A
KMT/KM-818	208	1	13	13	N/A
KMT/KM-818-30A	240	1	11	11	N/A
KMT/KM-818-30A	208	1	12	12	N/A
KMT/KM-714	120/208-240	1	10	20	N/A
KMT/KM-614	115	1	7	14	N/A

SPECIFICATIONS